

1. Place SofTie  
approximately where  
you want to attach  
the Shockle.



2. Fold flat end of the SofTie around the line and through the open loop.



3. Continue  
around the  
line again



**Soflie**  
800 lbs. Max Load  
shockles.com

4. Feed the flat end through the loop.



**5. Pull on the flat end to  
tighten the SofTie on the line.**



6. Clip the  
carabiner  
through the  
loop.



**7. Pull down on the Shockle to snug the SofTie onto the line.**

